

Ocularis DS

The Platform for IP Video Management

Quick Start Guide

On-Net Surveillance Systems, Inc.
One Blue Hill Plaza, 7th Floor, PO Box 1555
Pearl River, NY 10965
Phone: (845) 369-6400 | Fax: (845) 369-8711
Web: www.onssi.com | Email: sales@onssi.com

Legal Notice

This product manual is intended for general information purposes only, and due care has been taken in its preparation.

Any risk arising from the use of this information rests with the recipient, and nothing herein should be construed as constituting any kind of warranty.

© 2002-2009 On-Net Surveillance Systems, Inc. All rights reserved. OnSSI and the 'Eye' logo are registered trademarks of On-Net Surveillance Systems, Inc. Ocularis, Ocularis Client, Ocularis Client Lite, Ocularis Video Synopsis, NetEVS, NetDVMS, NetDVR, ProSight, NetGuard, NetGuard-EVS, NetSwitcher, NetMatrix, NetCentral, NetTransact, NetPDA and NetCell are trademarks of On-Net Surveillance Systems, Inc. All other trademarks are property of their respective owners.

On-Net Surveillance Systems, Inc. reserves the right to change product specifications without prior notice.

Getting Started with Ocularis

The following instructions will guide you through getting started with Ocularis – OnSSI’s open-architecture, non-proprietary PSIM (Physical Security Information Management) software platform.

A recommended process flow to prepare the video management environment with Ocularis on a new system is as follows:

1. Install the NVR software NetDVMS. See the *NetDVMS User Manual* for more details on installation of this application.
2. Create at least one administrative account on the NVR with full access rights.
3. Add and configure the IP video cameras and devices on the NVR.
4. Install the *Ocularis Client* on at least one workstation. See the *Ocularis Client User Manual* for additional instructions on installation.
5. Test connectivity of cameras by logging into the NVR using the *Ocularis Client*.
6. Install the Ocularis Base Server software on a dedicated server. Refer to the ‘Minimum System Requirements’ as defined on our website or in the *Ocularis Installation & Administration User Manual*.
 - Anti-Virus software must be disabled during the installation of the Ocularis Base component.
7. Install the *Ocularis Administrator* application on a workstation with network connectivity to the Ocularis Base Server. Refer to the ‘Minimum System Requirements’ as defined on our website or in the *Ocularis Installation & Administration User Manual*.
 - Prior to using *Ocularis Administrator*, you must license your copy of Ocularis DS. See the *Ocularis DS Licensing User Manual* for more details on how to activate the software.
8. Configure Ocularis Base using *Ocularis Administrator*. See the *Ocularis Installation & Administration User Manual* for more details.
9. Test connectivity of cameras by logging into Ocularis Base with *Ocularis Client*.
10. Install the remaining workstations with *Ocularis Client*.

Documentation

Additional documentation available for Ocularis DS includes:

NVR	<i>NetDVMS User Manual</i>
Ocularis Client	<i>Ocularis Client User Manual</i>
OnSSI Licensing	<i>Ocularis DS or Ocularis ES Licensing User Manual</i>
Add-On Applications	<i>Video Content Analytics User Manual</i>

Technical Support

For questions related to technical issues, contact OnSSI Technical Support at 845-732-7900 between the hours of 9:00 a.m. – 8:00 p.m. Eastern Time. Please have your SLC ready when calling for support.