



Ocularis™

Quick Start Guide

Legal Notice

This product manual is intended for general information purposes only, and due care has been taken in its preparation.

Any risk arising from the use of this information rests with the recipient, and nothing herein should be construed as constituting any kind of warranty.

© 2002-2010 On-Net Surveillance Systems, Inc. All rights reserved. OnSSI and the 'Eye' logo are registered trademarks of On-Net Surveillance Systems, Inc. Ocularis, Ocularis Client, Ocularis Client Lite, Ocularis Video Synopsis, NetEVS, NetDVMS, NetDVR, ProSight, NetGuard, NetGuard-EVS, NetSwitcher, NetMatrix, NetCentral, NetTransact, NetPDA and NetCell are trademarks of On-Net Surveillance Systems, Inc. All other trademarks are property of their respective owners.

On-Net Surveillance Systems, Inc. reserves the right to change product specifications without prior notice.

On-Net Surveillance Systems, Inc.
One Blue Hill Plaza | 7th Floor | PO Box 1555
Pearl River, NY 10965
T: 845.732.7900 | F: 845.732.7999
www.onssi.com

Getting Started with Ocularis™

The following high-level instructions will guide you through getting started with Ocularis – OnSSI's open-architecture, non-proprietary PSIM (Physical Security Information Management) software platform.

A recommended process flow to prepare the video management environment with Ocularis on a new system is as follows:

1. Install the NVR software. Follow the instructions in the *NetDVMS User Manual* or *NetEVS User Manual* for more details on installing these applications.
2. Create at least one administrative account on the NVR with full access rights.
3. Add and configure the IP video cameras and devices on the NVR.
4. Install the *Ocularis Client* on at least one workstation. See the *Ocularis Installation & Licensing Guide* for additional instructions on software installation.
5. Test connectivity of cameras by logging into the NVR using *Ocularis Client Lite*.
6. Install the Ocularis Base Server software on a dedicated server. Refer to the 'Minimum System Requirements' as defined on our website or in the *Ocularis Installation & License Guide*.
 - ⇒ Anti-Virus software must be disabled during the installation of the Ocularis Base component.
7. Install the *Ocularis Administrator* application on a workstation with network connectivity to the Ocularis Base Server. Refer to the 'Minimum System Requirements' as defined on our website or in the *Ocularis Installation & License Guide*.
 - ⇒ Prior to using *Ocularis Administrator*, you must license your copy of Ocularis. See the *Ocularis Installation & License Guide* for more details on how to activate the software.
8. Configure Ocularis Base using *Ocularis Administrator*. See the *Ocularis Administrator User Manual* for more details.
9. Test connectivity of cameras by logging into Ocularis Base with *Ocularis Client*.
10. Install the remaining workstations with *Ocularis Client*.

Documentation

Additional documentation for Ocularis includes:

<i>Ocularis Installation & Licensing Guide</i>
<i>Net DVMS or NetEVS User Manual</i>
<i>Ocularis Client/Client Lite User Manual</i>
<i>Ocularis Administrator User Manual</i>
<i>Ocularis Viewer User Manual</i>

Technical Support

Please see our website for detailed information and Ocularis downloads: <http://www.onssi.com/support.html>

For questions related to technical issues, contact OnSSI Technical Support at 845-732-7900 between the hours of 9:00 a.m. – 8:00 p.m. Eastern Time.

Please have your SLC ready when calling for support.



On-Net Surveillance Systems, Inc.
One Blue Hill Plaza 7th Floor
Pearl River, NY 10965
T: 845.732.7900 F: 845-732-7999
www.onssi.com

