

February 19, 2010

Release Notes for Ocularis Client Lite Rev 2.0

In this document:

1. General
2. Installation Notes
3. Feature Changes
4. Fixes

General

OnSSI Ocularis Client Lite 2.0 offers all of the functionalities of Ocularis Client 2.0 which do not involve connection to the Ocularis DS Base application. Version 2.0 includes the following changes:

Installation Notes:

- The new revision of the Ocularis Client requires uninstalling any previous version prior to installation.

Feature Changes

- Support for ImmerVision's IMV1 1/3 Panomorph lens

ImmerVision's IMV1 1/3 Panomorph lens, when attached to static IP cameras, provides a 360-degree field of view, thus replacing multiple static cameras. Ocularis Client Lite enables parsing the spherical ('fish-eye') video stream, so that it appears un-skewed. Panomorph-equipped cameras display in full screen and quad mode, and support database export, print report, and AVI export.

- Search filter fields in setup mode

Search filters for both view and camera names, are now available in Setup Mode. Any character or combination of characters will filter the views list to only the views or cameras containing the character or string of characters entered, highlighting those characters within the view or camera names.

- Quick-link access to cameras in live monitoring mode

Accessible via the camera pane circular menu, the camera drop-down menu, used for on-the-fly switching between cameras, now includes first letter quick-links. Clicking on a quick-link will scroll the alphabetical camera list to the desired letter.

Fixed issues:

- Aspect ratio calculation for digital PTZ
- BMP file rendering in a webpage view
- Improved viewport alignment